




40,000 BTU Forced Air PortaHeat Heater

Model Number

PortaHeat
PH40



For Pump Parts see Toro Round Pump Assembly

| Key No. | Part No. | Description |
|---------|----------|---------------------------|
| 1 | 221860 | Tube |
| 2 | 221949 | Fuel Tank |
| 3 | 147867 | Axle Bracket |
| 4 | 147776 | Axle |
| 5 | 154617 | Wheel |
| 6 | 147157 | Pushnut |
| 7 | 154008 | Power Cord |
| 8 | 147700 | Control Plate |
| 9 | 154012 | Reset, Circuit Breaker |
| 10 | 147774 | Support |
| 11 | 147775 | Handle |
| 12 | 154006 | Fan |
| 13 | 154484 | Motor Support |
| 14 | 73-6520 | Air Line |
| 15 | 147014 | Elbow |
| 16 | 154719 | Motor/Compressor Assembly |
| 17 | 154417 | Motor Strap |
| 18 | 148317 | Gasket, Tank Cap |
| 19 | 154021 | Tank Cap |
| 20 | 221879 | Access Cover |
| 22 | 223549 | Snap Bushing |

| Key No. | Part No. | Description |
|---------|----------|--------------------|
| 23 | 73-6520 | Fuel Line |
| 24 | 154468 | Fuel Filter |
| 25 | 147052 | Hose Fittings |
| 26 | 147081 | Nozzle Adapter |
| 27 | 154486 | Nozzle |
| 28 | 154360 | Cad Cell Assembly |
| 29 | 147836 | Lift Tube |
| 30 | 154009 | Transformer |
| 31 | 147080 | Spark Plug |
| | 147082 | Nozzle OORing |
| 32 | 147769 | Burner |
| 33 | 154537 | Combustion Chamber |

Parts Not Shown

| | |
|--------|-------|
| 147158 | Nut |
| 147000 | Screw |